

AV System - What do you need?

Audio Only

1. Turn the Speakers On
 1. Monacor Pre Amp Power
 2. Behringer Amp Power
2. Plug Ext Mini Jack into Device
Phone/Laptop etc
3. Turn up Behringer Amp
Volume to 12 o'clock
4. Start Playback
on Device
5. Turn up External Volume
to desired level
6. After use:
 1. Turn Off Behringer Amp
 2. Turn Off Monacor Amp
 3. Coil External Cable and replace on Hook

Laptop with Audio

1. Turn the System On
 1. Monacor Pre Amp Power
 2. Behringer Amp Power
 3. Turn on HDMI Switch
 4. Turn on TV
2. Ensure TV Source is HDMI 1
using SOURCE/INPUT button ➡
3. Plug Ext Mini Jack and HDMI Cable into Device
Apple HDMI Adaptor may be required, available for loan from Room Bookings
4. HDMI Switch should auto change to your device
If it doesn't then refer to Troubleshooting sheet for guidance.
5. Turn up Behringer Amp
Volume to 12 o'clock
6. Start Playback
on Device
7. Turn up External Volume
to desired level
8. After use:
 1. Turn Off Behringer Amp
 2. Turn Off Monacor Amp
 3. Turn Off TV
 4. Coil External Cable + HDMI and replace on Hooks

DVD Player

1. Turn the System On
 1. Monacor Pre Amp Power
 2. Behringer Amp Power
 3. Turn on HDMI Switch
 4. Turn on TV
2. Ensure TV Source is HDMI 1
using SOURCE/INPUT button ➡
3. Turn up Behringer Amp
Volume to 12 o'clock
4. Turn On DVD Player
Insert your disc and press play
5. HDMI Switch should auto change to DVD
If it doesn't then refer to Troubleshooting sheet for guidance.
6. Turn up HDMI Volume
to desired level
7. After use:
 1. Eject Disc and Turn off DVD
 2. Turn Off Behringer Amp
 3. Turn Off Monacor Amp
 4. Turn Off TV